

MC92N0-G


QUICK START GUIDE

<http://www.zebra.com/mc92n0-g>


See User Guide for more information

BATTERY INSERTION


Front View




Battery Removal



Stylus Removal




SNAP-ON ACCESSORY INSTALLATION




CHARGING INSTRUCTIONS


⦿ = LED Indicator Location Slow Flash = Normal Charge Solid Amber = Full Charge Fast Flash = Charging Error



Four Slot Spare Battery Charger




Single Slot Serial/USB Cradle







Four Slot Cradles
Charge-Only Cradle and Ethernet Cradle

OPTIMUM IMAGING AND SCANNING POSITIONS



Laser Scanning



Standard Range Imaging




Long Range Imaging



OPTIMUM UPRIGHT BODY POSTURE



AVOID EXTREME WRIST ANGLES




ALTERNATE LEFT AND RIGHT HANDS
TAKING BREAKS AND TASK ROTATION RECOMMENDED



OPTIMUM BODY POSTURE

Low Scanning
Alternate left and right knees



Alternate left and right hands



High Scanning
Use a ladder



Taking breaks and
task rotation recommended

POST IN WORK AREA



Zebra Technologies Corporation
Lincolnshire, IL U.S.A.
Zebra and the Zebra head graphic are registered trademarks of ZIH Corp. The Symbol logo is a
registered trademark of Symbol Technologies, Inc., a Zebra Technologies company.
© 2015 Symbol Technologies, Inc.



72-161751-02 Rev B – April 2015



<http://www.zebra.com/mc92n0-g>